

Metal Roofing California website is owned and operated by Western Metal Deck WESTERN METAL DECK

(909) 467-2016 • METALROOFINGCALIFORNIA.COM

R PANEL / PBR PANEL

INSTALLATION GUIDE WITH TRIM, FLASHINGS AND DETAILS



4170-22

Western Metal Deck 616 S. Oaks Ave. Ontario, CA 91762

☎ (909) 467-2016
 ☑ sales@metalroofingcalifornia.com


For More Information: METALROOFINGCALIFORNIA.COM



Western States R Panel

Installation, Flashings & Shop Drawing Detail Guide

Table of Contents



PBR Panel

Section	Page
Notes to Designer / Installers	. 1
Fastener Placement and Selection	2-3
Key Roof Plan	4
Key Flashing / Trims	5-6-7-8
Eave Detail	9
Mini Eave Detail	10
Eave Pre Hung Gutter	11
Eave Post Hung Gutter	12
Gutter Splice	13
Gable Flashing	14
Mini Gable Flashing	15
Sculptured Gable	16
Universal Gable Flashing	17
Peak/ High Eave	18
Sidewall	19
Endwall	20
Formed Ridge	21

Section I	Page
Hip and Ridge	22
Valley	23
Pitch Break High to Low	24
Pitch Break Low to High	25
Chimney26-27-	-28-29
Pipe Flashing	30
Head & Jamb Details	31
Wall Detail Isometric	32
Wall Base Flashing	33
Outside Corner	34
Inside Corner	35
Notes	36
Custom Trim Form	37
Special Design Considerations	38

Western States "R" Panel

Installation, Flashings & Shop Drawing Detail Guide

Notes to Designer and Installers

The details contained in this guide are proven industry details and are intended to be used as a design aid and installation guide. It does not depict all situations that may be encountered on all projects. Modifications are the responsibility of the designer/ owner/ installer. Consideration should be given for Fit for Purpose, Building use, Climate conditions such as temperature, snow, wind, and moisture, Governing Building Codes, and Maintenance. It is highly recommended that all trims and flashings be of the same material as the panels (metal, gauge, finish) to ensure long term performance and durability. Where possible, flashing edges should be hemmed to strengthen the edge and protect the cut edge from exposure.

Framing and Substrates

"R " panels are used over all type of substrates like Steel Decking, open purlins, spaced sheathing, and wood decking such as plywood. Most details in this guide are shown with panels attached to Purlins.

Note on underlayment

Not all conditions require an underlayment, However metal roofing is susceptible to Condensation and it is recommended that an appropriate Roofing underlayment be use on all wood substrates to protect the structure during installation. For added protection from rain and snow, it is recommended to use rubberized Ice and water shield on eaves, valleys, and areas of roof penetrations.

Slope Requirements

It is recommended that "R" panels have a minimum slope requirement of 1:12 on all structures.

Valley and Snow Design

Valley design and dimension must be the proper width to accommodate high snow, rain, ice, and slope conditions. If possible, splices, penetrations, valleys, roof elevation changes, should be minimized in areas of high snow and ice accumulations.

Oil Canning

Oil canning is a condition common with flat metal surfaces. This waviness is caused by steel mill tolerances, forming, variations in the structures surfaces, and hardness of the steel. Measures are taken at the roll forming process, like profile design, steel gauge, corrective leveling, to minimize the effects of oil canning. Oil Canning is a Characteristic of steel and can not be eliminated totally and therefore is not reason for rejection of the panels.

Job Site Storage

While waiting to be installed on the job site, Storage of panels, trim crates, and flat sheet should be sloped in order to allow for proper moisture run off. One end should be elevated so as not to allow ponding of water on the metal surface. When using tarps for protection, proper ventilation should be provided to prevent condensation. Moisture or condensation that is trapped inside a bundle can lead to white rust on sheeting.

References

For other installation techniques and details, The Sheet Metal and Air Conditioning Contractors National Association Inc. (SMACNA) and NRCA manuals are great resources for working with sheet metal.


Technical Assistance

Contact your WSDI sales or technical representative for any additional information or assistance.

Western States Metal Roofing "R" Panel


Installation, Flashings & Shop Drawing Detail Guide

Fastener Placement and Selection



Notes to Installers:

- Fastener Selection will vary depending on type and thickness of substrate.
- Space panel lap screws 12" minimum -24" O.C. maximum. Consult with design engineer.
- Spacing of fastener rows to be engineered by others.
- Lap panels away from prevailing winds whenever possible.
- The use of Butyl tape mastic is always recommended on the panel lap when used for roof panels.
- Panels and flashings should never be installed in contact with dissimilar metals.
- Use only those flashings and accessories designed for use with this panel.
- Panel attachment screws must be long enough to fully penetrate through roof deck substrate or penetrate solid lumber at least one inch.
- Exposed Fasteners should have sealing washers and be coated to provide protection against corrosion.
- Screws must be properly driven to ensure holding strength and proper seal. (see diagram)
- Recommended drill speed is 2000rpm. Improper setting of drill speed can lead to snapping of screw heads.
- Pre drilling of screw holes may be necessary with heavy gauge metals.




Western States Metal Roofing "R" Panel

Installation, Flashings & Shop Drawing Detail Guide

Fastener Selection Description	Application	
#9 x1" Wood Drillers #9 x 1.5" Wood Drillers #9 x2" Wood Drillers	Used to attach panels to dimensional Lumber and plywood	
#12-14 x 1" SD #12- 14 x1.5" SD #12- 14 x 2" SD #12-24 x1.25 SD	Used to attach panels to Purlins and other metal substrates	
¼ x 7/8″ Lap Self tap ¼″ x7/8 Lap Stainless	Used to attach Trims and panel side laps. Stainless to be used with A606-4 Steel	The second secon
#10-12 x1" Pancake Wood #10-12 x 1" SD Self Driller	Used to secure trims to substrates. Also available in Stainless Steel.	
1/8" Stainless Rivets	Used for Trim to Trim attachment or trim to wall panels.	
Stainless Screws #10 x1 Wood Drillers #10 x 1.5 Wood Drillers #10 x 2″ Wood Drillers	Used for panel attachment for panels made with A606-4 Steel	ernnnnnnnt []

The table above shows the panel Fasteners provided by WSD. Special order screws are available.


	FLASHING TYPE STANDARD TRIM STANDARD TRIM STANDARD TRIM STANDARD TRIM EAVE MINE EAVE EAVE-PRE-HUNG GUTTER EAVE-POST-HUNG GUTTER POST-HUNG GUTTER SPLICE GABLE FLASHING MINI GABLE FLASHING SCULPTURED GABLE FLASHING UNIVERSAL GABLE FLASHING SIDEWALL FLASHING ENDWALL FLASHING FORMED RIDGE RIDGE-HIP VALLEY FLASHING PITCH BREAK HIGH TO LOW PITCH BREAK LOW TO HIGH CHIMNEY FLASHING CHIMNEY FLASHING CHIMNEY FLASHING CHIMNEY FLASHING CHIMNEY FLASHING SIDMETRIC DETAIL PIPE FLASHING WALL DETAIL WALL DETAIL WALL DETAIL WALL DETAIL WALL DETAIL WALL DETAIL NOTES CUSTOM TRIM SHEET	DETAIL NO. WSD-ST5 WSD-ST6 WSD-ST7 WSD-ST8 WSD-E1 WSD-ME1 WSD-EPRG1 WSD-EPOG2 WSD-EG3 WSD-GF2 WSD-GF2 WSD-GF2 WSD-GF2 WSD-UGF2 WSD-V7 WSD-PK3 WSD-SW4 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR6 WSD-FR10 WSD-CF10 WSD-CF10 WSD-CF11 WSD-CF12 WSD-CF13 WSD-PF14 WSD-W15 WSD-W16 WSD-W17 WSD-W18 WSD-W19 WSD-N20 WSD-CT21
901 W. Watkins St. Phone: (602) 495-0048 Phoenix, AZ 85007 Fax: (602) 261-7726	DETAIL: KEY ROOF PLAN PANEL TYPE: R-Panel	B 01-14-13 A 06-18-12 REV: DATE: DETAIL #:





EXTENDED VALLEY WS-225	PEAK FLASHING WS-219	JAMB TRIM WS-203	HEAD TRIM WS-208
18 3/4" * DENOTES ANGLE	S* (HARJES) COLOR SIDE COLOR	1/2 1/4" 80 mm	2 3/8" to color side 1/2" HEM 1 1/4"
BASE TRIM WS-206	ENDWALL FLASHING WS-228	SIDEWALL FLASHING WS-207	RIDGE/HIP CAP WS-205
The second secon	* DENOTES ANGLE	COLOR SIDE 3 3/4" 4 7/8" 1/2" HEM	* DENOTES ANGLE
RIDGE/HIP CAP WS-205H	RIDGE/HIP CAP WS-220	RIDGE/HIP CAP WS-220H	DIE FORMED RIDGE CAP WS-221
T T T T T T T T T T T T T T	COLOR SIDE	10" 10" 10" 10" 10" 10" 10" 10"	* <u>6:12 PITCH MAX.</u> * <u>6:12 PITCH MAX.</u> 18" A <u>18"</u> * <u>AVAILABLE IN 24GA ONLY</u>
Phoenix, AZ 85007 Fa	al Roofing ne: (602) 495-0048 nx: (602) 261-7726 PURLINS (787-5467)	PA	STANDARD TRIM B 01-14-13 A 06-18-12 REV: DATE: DETAIL #: WSD-ST6


OUTSIDE CORNER WS-202	INSIDE CORNER WS-230	CRICKET FLASHING CUSTOM TRIM W	S-299 SCULPTURED PRE-HUNG GUTTER WS-201
3 3/4" 1/2" 3/4" HEM 1/2" 3/4" HEM 1/2" 1/2" 3/4" HEM 1/2"	"TOTAL A 1/8" 1/2" 3/4" 1/2" 1/2" 1/2" HEM	* DENOTES ANGLE	* DENOTES ANGLE 4"
BOX GUTTER PRE-HUNG WS-210	BOX GUTTER POST-HUNG WS-215	SCULPTURED POST-HUNG GUTTER W	S-217 SPLICE WS-213 FOR BOX GUTTER
• DENOTES ANGLE • DENO	ODEN HEM 1 1 4 1 1 4 1 1 1 4 1 COLOR SIDE 4 1 0 DENOTES ANGLE	1" * DENOTES ANGLE	DE * 12" LONG * 14 * 10 * 14 * 10 * 14 * 10 * 0 * 0 * 0 * 0 * 0 * 0 * 0 *
SPLICE WS-260 FOR SCULPTURED GUTTER	DOWNSPOUT STRAIGHT WS-226	DOWNSPOUT WITH KICKOUT WS-2	27 DOWNSPOUT ELBOW WS-243
* 12" LONG * 12" LONG * 12" LONG * 12" LONG * 00 * 00	3 1 12" COLOR SIDE	COLOR SIDE COLOR SIDE "45 DEG. BEND UNLESS NOTED"	3 1/2" COLOR SIDE "45 DEG. BEND UNLESS NOTED"
Phoenix, AZ 85007 Fa	al Roofing he: (602) 495-0048 x: (602) 261-7726 PURLINS (787-5467)	PAN	STANDARD TRIM EL TYPE: R-Panel B 01-14-13 A 06-18-12 REV: DATE: DETAIL #: WSD-ST7


DOWNSPOUT STRAP WS-242	DOWNSPOUT OUTLET WS-275	GUTTER STRAP WS-212	BOX GUTTER END CA	P WS-214
1/2" HEM 1/2" HEM 1/2" HEM 1/2" HEM 1/2" HEM 1/2" HEM 1/2" HEM 1/2" HEM	at the second se	5/8" HEM	VIEW 3 15/16"	1" TABS
SCULPTURE GUTTER END CAP WS-249				
3 15/16" 1 1/4" 3 5/16" 1 1/4" 3 15/16" 3 15/16"				
Phoenix, AZ 85007 Fa	al Roofing ne: (602) 495-0048 nx: (602) 261-7726 PURLINS (787-5467)		STANDARD TRIM	B 01-14-13 A 06-18-12 REV: DATE:
www.RustedRoofing.com www.MetalDeck.com		PANI	R-Panel	DETAIL #: WSD-ST8













































































NOTES:		
Western States Metal Roofing		
901 W. Watkins St. Phone: (602) 495-0048	NOTES	B 01-14-13 A 06-18-12
Phoenix, AZ 85007 Fax: (602) 261-7726 www.MetalForRoofing.com 877-PURLINS (787-5467)	PANEL TYPE:	REV: DATE:
www.RustedRoofing.com www.MetalDeck.com	R-Panel	DETAIL #: WSD-MN19

CUSTOM TRIM

		GAUGE:	COLO	DR:	
		BREAKS:	FINIS	SH:	
		LENGTH:	STRI	ЕТСН ОІ	JT:
		MATERIAL:			
Western States	s Metal Roofing	CUSTOM TRIM NAME:			
901 W. Watkins St.	Phone: (602) 495-0048			В	01-14-13
Phoenix, AZ 85007	Fax: (602) 261-7726			Α	06-18-12
www.MetalForRoofing.com	877-PURLINS (787-5467)	PANEL TYPE:		REV:	DATE:
www.RustedRoofing.com www.MetalDeck.com		R-Panel		DETAIL #	^{#:} D-CT20

Western States "R" Panel

Installation, Flashings & Shop Drawing Detail Guide

Special Design Considerations

The details contained in this guide are proven industry details and are intended to be used as a design aid and installation guide. It does not depict all situations that may be encountered on all projects. Modifications are the responsibility of the designer/ owner/ installer.

Consideration should be given for Fit for Purpose, Building use, Climate conditions such as temperature, snow, wind, and moisture, Governing Building Codes, and Maintenance.

It is highly recommended that all trims and flashings be of the same material as the panels (metal, gauge, finish) to ensure long term performance and durability. Where possible, flashing edges should be hemmed to strengthen the edge and protect the cut edge from exposure.

Acceptance

Use of this manual is strictly voluntary. Details that are provided are to be used as a guide only. Details may not be applicable for all situations. This guide provides one standard detail and WSDI accepts that other installation details may be needed and other details may exist. WSDI makes no guarantee as to the Weather Tightness of the system or details found with in this guide. The information in this manual is believed to be correct and accurate at the time of printing. WSDI reserves the right to change details, discontinue products, change designs at any time without incurring obligation. It is best to consult your Design Engineer for recommendations.

Underlayment

There are many types of underlayment's on the market today. All designed with a special purpose depending on the type of Metal and profile. Many different types of metal will require a different type of underlayment, such as A606-4 (Corten) which requires a High Temperature underlayment. It is best to consult your Design Engineer for recommendations.

Valley and Snow Design

Valley design and dimension must be the proper width to accommodate high snow, rain, ice, and slope conditions. If possible, splices, penetrations, valleys, roof elevation changes, should be minimized in areas of high snow and ice accumulations. Details found in this manual may not pertain in areas of high snow and ice accumulations.

Panel Coverage and Fastening

Normal panel width of "R" panel is 36". However depending on the finish selected and the required coil feed, it may be necessary for WSD to shorten the width of the panel. Please consult with your WSDI representative for details and fastening recommendations.

Safety and Maintenance

Walking on and installing any roof is dangerous! Extreme care should always be used when walking on roofs. Safety should always be a top priority and approved fall protection and equipment as approved by OSHA should always be used.

No roof is immune to severe weather or is completely maintenance free. To keep your roof performing as it was designed; an inspection and comprehensive maintenance program should be implemented.

References

For other installation techniques and details, The Sheet Metal and Air Conditioning Contractors National Association Inc. (SMACNA) and NRCA manuals are great resources for working with sheet metal.

Technical Assistance

Contact your WSDI sales or technical representative for any additional information or assistance. To insure you have the latest information available, please inquire or visit our web sites at www.metaldeck .com or Rustedroofing.com



Metal Roofing California website is owned and operated by:

WESTERN METAL DECK

(909) 467-2016 • METALROOFINGCALIFORNIA.COM

REQUEST A FREE METAL COLOR SAMPLE

Pick Up or Delivery (Available anywhere on the West Coast)

Western Metal Deck

616 S. Oaks Ave., Ontario, CA 91762 ☎ (909) 467-2016 ⊠ sales@metalroofingcalifornia.com



https://www.facebook.com/westernmetaldeck/

https://www.instagram.com/westernmetaldeck1/

https://twitter.com/WesternDeck

https://www.youtube.com/channel/UCsZltingwPEu_ElXLXZ8Dvg